



HOMESTREAM TV

Amazon Fire TV Stick 4K Max Functions

Cloud DVR

- To access your Cloud DVR recordings, simply click the **Menu** button (three horizontal bars) on the remote control.
- Scroll to the right using the right side of the **Directional Navigation** button until you highlight the profile icon.
- You are now able to manage your Cloud DVR. By default, you will see the recordings that are currently available to you. You have to click the bottom of your **Directional Navigation** button to highlight the title you'd like to play. Click the **Select** button to begin watching.
- If you want to manage your upcoming recordings, scroll up until "Recorded" is highlighted at the top of your screen, then navigate to the right to select "Scheduled". From here, you can manage all of your upcoming recordings.

Restart

- When you click over to a program currently in session and that program is capable of using the Start Over feature, you will be prompted with a pop up: "Play from the Beginning?". All you have to do is click the **Select** button on your remote control to select "Yes".
- If you decide later that you'd like to watch a program from the beginning, you can do that easily as well. Click the **Select** button on your remote, then scroll over to "Restart". Once you click the **Select** button again, your program will start from the beginning.

Replay

- To access Replay, select Guide after clicking the **Menu** button.
- Click the left side of your **Directional Navigation** button. You will see a new menu pop up with "Replay" highlighted.
- Click the **Select** button on your remote control.
- From here you can browse programs and movies available to be replayed. Simply select a title to begin watching.



Filters

- To access your filters, select Guide after clicking the **Menu** button.
- Click the left side of your **Directional Navigation** button. You will see a new menu pop up. Click the bottom of your **Directional Navigation** button to highlight "Filters". Click the **Select** button on your remote.
- From here, you can select from various categories that you are interested in viewing.
- To return to the previous screen, click the **Back** button on your remote.

Search

- To easily search for the content you want to watch, click the **Menu** button on your remote.
- Using your **Directional Navigation** button, scroll to the right until you highlight the magnifying glass icon. Click the **Select** button.
- Begin typing the title of what you are searching for. When you are finished, select "Next".
- Instead of typing, you can also hold the **Microphone** button on your remote and say the name of what you'd like to search for and release the button. Your search results will now populate so you can scroll and enjoy.

Visit MyHomeStreamTV.com for more tips and tricks!